

Congratulations!
You have chosen to purchase a high-quality product. Familiarise yourself with the product before using it for the first time.

Read the following instructions for use carefully.

Use the product only as described and only for the given areas of application. Store these instructions for use carefully. When passing the product on to third parties, please also hand over all accompanying documents.

Package contents (Fig. A)
1 x bicycle smartphone holder (1)
1 x adapter (1a)
1 x bag bracket (2)
1 x instructions for use

Technical data
Date of manufacture (month/year): 11/2023

max. 0,4 kg
Maximum load: 0,4 kg

- For bicycle handlebars with a diameter of 16,5–35mm
- Dimensions: approx. 20 x 10,5 x 9cm (W x H x D)

• Dimensions of viewing window: approx. 17,4 x 9,3cm (L x W)

Intended use
This product has been developed as a smartphone storage bag for personal use on your bicycle. It is not suitable for use on motorbikes, scooters or similar vehicles.

Safety information
 Life-threatening hazard!
Never leave children unattended with the packaging materials. There is a risk of suffocation!

Risk of injury!
• **WARNING!** Read all safety information and instructions.
• Using a smartphone when cycling affects concentration and is prohibited. Cycle to the side of the road and get off the bike before taking or making a call.
• The distributor is not responsible for any damage caused to smartphones due to use of the product.
• The use of headphones affects concentration and is prohibited in some states. Find out about the laws and regulations in the states where you use your bicycle and always follow the rules.



PDF ONLINE
www.lidl-service.com

- Remove the product from the handlebars when not in use.
- Do not use the product when it is raining because water can penetrate through the zip fastener and viewing window.
- Check the product for damage or wear before each use.
- Check that all screw connections are firmly secured before each use. The product may be used only if it is in perfect condition!
- Use of the product must not affect the functionality of the bicycle. It must not obstruct any reflectors or lights. No Bowden cables should be bent or pinched.

- Always assemble and disassemble the product without the presence of a smartphone. Otherwise this may be damaged.

Assembly
Assembling the bracket (Fig. B)

- Remove the protective caps (2e) from the screws (2c).
- Loosen the screw caps (2d) from the screws.
- Pull both halves of the bracket (2a, 2b) apart and place them around the handlebar.
- Put the screw caps on the screws and tighten the screw caps.

Note: if the screws (2c) are sticking out from the screw caps (2d), put the screw caps (2e) on again.

Attaching the bag (Fig. C)
Put the bag (1) with the locking button (1b) facing upward on the adapter of the handlebar bracket (2b) until it audibly clicks into place.

Important: the product has only properly clicked into place if the locking button as shown in Fig. C is visible.

Remove the bag (Fig. C)
Press down the locking button (1b), and pull the bag away from the adapter (2).

Cable hole (Fig. D)

- Place your smartphone into the bag (1).
- Connect the headphones/charging cable to the smartphone.
- Guide the headphones/charging cable through the cable hole (1c).

Important: ensure that no cables (particularly for large smartphones) become disconnected.

Adjusting the position (Fig. E)

Press down the locking button (1b). Turn the product right or left to set your desired position. The product clicks into place at 90° intervals.


Storage, cleaning

When not in use, always store the product clean and dry at room temperature. Wipe clean with a dry cloth only. **IMPORTANT!** Never clean with abrasive cleaning agents.

Disposal

Dispose of the product and packaging materials in accordance with current local regulations. Store the packaging materials (foil bags, for example) out of the reach of children. For further information about disposal of the product no longer needed, contact your local council.

Dispose of the product and the packaging in an environmentally friendly manner.



The Recycling Code distinguishes different materials to be returned for recycling. The Code consists of the recycling symbol for the recycling process and a number that identifies the material.

Notes on the guarantee and service handling

The product was produced with great care and under continuous quality control.

DELTA-SPORT HANDELSKONTOR GmbH gives private end customers a three-year guarantee on this product from the date of purchase (guarantee period) in accordance with the following provisions. The guarantee is only valid for material and manufacturing defects. The guarantee does not cover parts subject to normal wear and tear that are thus considered wear parts (e.g. batteries) or fragile parts such as switches, rechargeable batteries, or parts made of glass.

Claims under this guarantee are excluded if the product has been used incorrectly, improperly, or contrary to the intended purpose, or if the provisions in the instructions for use were not observed, unless the end customer proves that a material or manufacturing defect exists that was not caused by one of the aforementioned circumstances. Claims under the guarantee can only be made within the guarantee period by presenting the original sales receipt.

Please therefore keep the original sales receipt. The guarantee period is not extended by any repairs carried out under the guarantee, under statutory guarantees, or as a gesture of goodwill. This also applies to replaced and repaired parts. If you wish to make a claim please first contact the service hotline mentioned below or contact us by e-mail. If there is a guarantee case, then the product will be repaired or replaced free of charge to you or the purchase price will be refunded, depending on our choice.

Your legal rights, in particular guarantee claims against the respective seller, are not limited by this guarantee.

IAN: 455395_2304
GB Service Great Britain
Tel.: 0800 404 7657
E-Mail: deltasport@lidl.co.uk

Gefeliciteerd!
Met uw aankoop hebt u voor een hoogwaardig artikel gekozen. Zorg ervoor dat u voor het eerste gebruik met het artikel vertrouwd raakt.

Lees hiervoor de volgende gebruiksaanwijzing zorgvuldig door.

Gebruik het artikel alleen zoals omschreven en voor het aangegeven doel. Bewaar deze gebruiksaanwijzing goed. Geef alle documenten mee als u het artikel aan iemand anders geeft.

Leveringsomvang (afb. A)
1 x fiets-telefoonhoesje (1)
1 x adapter (1a)
1 x hoeshouder (2)
1 x gebruiksaanwijzing

Technische gegevens
Productiedatum (maand/jaar): 11/2023

max. 0,4 kg
Maximale belasting: 0,4 kg

- Voor fietssturen met een diameter van 16,5 - 35 mm
- Afmetingen: ca. 20 x 10,5 x 9 cm (b x h x d)
- Afmetingen kijkvenster: ca. 17,4 x 9,3 cm (l x b)

Beoogd gebruik
Dit artikel is ontwikkeld als opberghoes voor een smartphone op de fiets en bestemd voor particulier gebruik. Het is niet geschikt voor montage op motorfietsen, scooters en soortgelijke voertuigen.

Veiligheidsstips

Levensgevaar!
Laat kinderen nooit zonder toezicht alleen met het verpakkingsmateriaal. Er bestaat verstikkingsgevaar!

Kans op lichamelijk letsel!

- WAARSCHUWING!** Lees alle veiligheidsstips en aanwijzingen.
- Het gebruik van een smartphone tijdens het fietsen beïnvloedt de aandacht en is verboden. Rijd naar de rand van de weg en zet uw fiets neer, voordat u een telefoontje aanneemt of zelf iemand belt.
- De distributeur is niet aansprakelijk voor eventuele schade aan smartphones die door het gebruik van het artikel is ontstaan.

