

DOG HARNESS

GB IE NI
DOG HARNESS
Instructions for use





DK
HUNDESELE
Brugervejledning

FR BE
HARNAIS POUR CHIEN
Notice d'utilisation

NL BE
HONDENHARNAS
Gebruiksaanwijzing

DE AT CH
HUNDEGESCHIRR
Gebrauchsanweisung

IAN 340700_1910



Congratulations!
You have chosen to purchase a high-quality product. Familiarise yourself with the product before using it for the first time.
Read the following instructions for use carefully.

Use the product only as described and only for the given areas of application. Store these instructions for use carefully. When passing the product on to third parties, please also hand over all accompanying documents.

Package contents
1 x dog harness
2 x hook and loop sticker
1 x instructions for use

Technical data
Size S (HG-7681):
Chest measurement: approx. 38-50cm,
Size M (HG-7682):
Chest measurement: approx. 51-67cm,
Size L (HG-7683):
Chest measurement: approx. 70-86cm,

Size XL (HG-7684):
Chest measurement: approx. 90-119cm
Date of manufacture (month/year): 04/2020

Intended use
This product is designed for private use as a harness for dogs with a chest circumference of approx. 38-50cm for size S, approx. 51-67cm for size M, approx. 70-86cm for size L, and approx. 90-119cm for size XL. Only feed the harness over the lead manually. The product must not be used to tether the dog.

Safety information

- Risk of injury!**
- Only use the product for its intended purpose.
 - Keep the packaging materials and the product away from children.
 - Check the product for damage or wear before each use. Only use the product if it is in perfect condition!
 - Release the dog immediately if it becomes entangled in the product.

- Note that smaller dogs can be quite strong. Children and older persons may not be able to control them.
- It is your responsibility to keep the dog under control at all times.
- Think ahead as to how your dog may react in critical situations.
- You should bring your dog to your side in the event of possible risk situations. Pay particular attention to other people and to your animal when on pavement or when crossing cycling paths.
- The dog should be led at heel with a strong grip on the lead and the harness if other persons or animals are close by.
- Dogs pose a hazard to wild animals, particularly during breeding season. Each dog reacts differently. Act in a responsible manner and ensure that nobody is endangered or hindered.
- Let the lead hang loose if the dog should move backwards and try to pull itself out of the harness.
- If the straps are too loose, there is the risk that the dog can pull them off from the front.
- It can be uncomfortable for the dog if the product is too tight.

Use
Determining the correct size (Fig. A)

The correct choice of size is important for the safe and comfortable use of the product. Determine the correct size as follows:
For sizes L and XL, there must be a space of four finger widths between the belly and front legs. This space is two finger widths for size M, and one finger width for size S. The size is correct if the dog can move its front legs freely.

Note: if the product is too large then there is a risk that the dog will step out of the product with its front legs.

Attaching the product correctly

- Open the hook and loop fastener on the chest strap (1) and guide the product over the dog's head.
- Close the belly strap (2) and tighten it by pulling upward on the buckle (Fig. B).

Note: make sure that two fingers fit between the product and the dog's back.

3. Tighten the hook and loop fastener on the chest strap until two fingers fit between the chest and the strap.

Note: guide the hook and loop fastener inside along the chest (Fig. C).

Applying the hook and loop stickers (Fig. D)

You can apply the enclosed hook and loop stickers (3) to the corresponding attachment surfaces (4) on the sides of the harness. All attachment surfaces must always be clean. Make sure that there are no dog hairs between the sticker and the attachment surfaces when applying them.

Storage, cleaning

The product must regularly be cleaned mechanically for reasons of functionality. When not in use, always store the product clean and dry at room temperature. Do not expose the product to direct sunlight. **IMPORTANT!** Never clean the product with harsh cleaning agents.



The product must be disinfected if the animal is or has been ill. You should consult a veterinarian you trust and ask for a suitable cleaner and disinfectant.

Disposal

Dispose of the article and the packaging materials in accordance with current local regulations. Packaging materials such as foil bags are not suitable to be given to children. Keep the packaging materials out of the reach of children.

Dispose of the products and the packaging in an environmentally friendly manner.

The recycling code is used to identify various materials for recycling. The code consists of the recycling symbol – which is meant to reflect the recycling cycle – and a number which identifies the material.

Notes on the guarantee and service handling

The product was produced with great care and under constant supervision. You receive a three-year warranty for this product from the date of purchase. Please retain your receipt.

The warranty applies only to material and workmanship and does not apply to misuse or improper handling. Your statutory rights, especially the warranty rights, are not affected by this warranty. With regard to complaints, please contact the following service hotline or contact us by e-mail. Our service employees will advise as to the subsequent procedure as quickly as possible. We will be personally available to discuss the situation with you.

Any repairs under the warranty, statutory guarantees or through goodwill do not extend the warranty period. This also applies to replaced and repaired parts. Repairs after the warranty are subject to a charge.

IAN: 340700_1910
Service Great Britain
Tel.: 0800 404 7657
E-Mail: deltasport@lidl.co.uk
Service Ireland
Tel.: 1890 930 034
(0,08 EUR/Min., peak)
(0,06 EUR/Min., off peak)
E-Mail: deltasport@lidl.ie



DELTA-SPORT HANDELSKONTOR GMBH
Wragelkamp 6 • DE-22397 Hamburg
GERMANY

04/2020
Delta Sport-Nr.: HG-7681/HG-7682/HG-7683/HG-7684

Hjertelig tillykke!
Du har valgt at købe et kvalitetsprodukt. Lær produktet at kende, inden du bruger det første gang.
Det gør du ved at læse nedenstående brugervejledning omhyggeligt.
Brug kun produktet som beskrevet og til de angivne anvendelsesområder. Opbevar denne brugervejledning et sikkert sted. Udlever også alle dokumenter, hvis produktet videregives til en tredjepart.

Leveringsomfang
1 x hundesele
2 x burremærkat
1 x brugervejledning

Tekniske data
Størrelse S (HG-7681):
Brystmål: ca. 38-50 cm,
Størrelse M (HG-7682):
Brystmål ca. 51-67 cm,
Størrelse L (HG-7683):
Brystmål ca. 70-86 cm,
Størrelse XL (HG-7684):
Brystmål ca. 90-119 cm

Fremstillingsdato (Måned/år): 04/2020

Bestemmelsesmæssig brug
Denne artikel er udviklet til privat brug som sele til hunde med et brystmål på ca. 38-50 cm i størrelse S, på ca. 51-67 cm i størrelse M, på ca. 70-86 cm i størrelse L og på ca. 90-119 cm i størrelse XL. Før kun selen med hånden via snoren. Artiklen må ikke anvendes til at binde hunden fast med.

Sikkerhedsanvisninger

Fare for kvæstelser!

- Anvend kun artiklen til det tilsigtede formål.
- Opbevar emballagematerialet og artiklen utilgængeligt for børn.
- Kontroller artiklen for skader og slitage inden hver brug. Artiklen må kun anvendes i fejlfri stand!
- Befri hunden med det samme, hvis den er blevet viklet ind i artiklen.
- Vær opmærksom på, at mindre hunde også kan være ret stærke. Børn og ældre personer kan måske ikke beherske dem.
- Det er dit ansvar altid at have kontrol over hunden.

- Overvej på forhånd din hunds mulige adfærd i kritiske situationer.
- Kald hunden til dig inden mulige faresituationer. Vær især opmærksom på andre personer og deres dyr på stier og fortove, og når du krydser en vej.
- Hvis andre personer eller dyr er i nærheden, skal du føre hunden til fods og med fast greb i snoren og selen.
- Især i brunst- og fødselsperioder er hunde til fare for vilde dyr. Alle hunde reagerer forskelligt. Vær bevidst om dit ansvar og sørg for, at ingen udsættes for fare eller gene.
- Hvis hunden går baglæns og forsøger selv at komme ud af selen, skal snoren løsnes lidt.
- Hvis remmene er for løse, er der fare for, at hunden kan slippe løs foran.
- Hvis artiklen er indstillet for stramt, kan den være ubehagelig for hunden.

Brug
Beregning af den rigtige størrelse (fig. A)

Det er vigtigt for sikker og bekvem brug af artiklen at vælge den rigtige størrelse.

Beregn den rigtige størrelse som følger:
Ved størrelse L og XL skal der være fire fingerbredders afstand mellem bug og forben.
Ved størrelse M to fingerbredder og ved størrelse S én fingerbredde. Størrelsen er rigtig, når hunden kan bevæge forbenene frit.
Bemærk: Hvis artiklen er for stor, er der fare for, at hunden kan krybe ud af artiklen med forbenene.

Korrekt påsætning af artiklen

- Åbn burrebåndet på bugremmen (1), og før artiklen over hovedet på hunden.
- Luk bugremmen (2), og stram den ved at trække opad i spændet (fig. B).
- Luk burrebåndet på brystremmen så meget, at der er plads til to fingre mellem bryst og rem.


Bemærk: Læg burrebåndet langs med brystet på indersiden (fig. C).

Påsætning af burremærkat (fig. D)

De medfølgende burremærkater (3) kan anbringes på siden af selen på de tilhørende flader (4).
Alle burreflader skal altid være rene. Sørg for, at der ikke kommer hundehår imellem mærkat og burreflader, når du sætter dem på.

Opbevaring, rengøring

Artiklen skal regelmæssigt rengøres af hensyn til funktionaliteten. Opbevar altid artiklen tør og ren ved stuetemperatur, når den ikke er i brug. Må ikke udsættes for direkte sollys.



forbindelse med eller efter dit dyr har været sygt, skal artiklen desinficeres. Kontakt en dyrlæge, og spørg om egnede hygiejne- og desinfektionsmidler.

Henvisninger vedr. bortskaffelse

Bortskaf artikel og emballage i overensstemmelse med lokalt gældende forskrifter. Emballagematerialer som f.eks. plastposer hører ikke hjemme i børnehænder. Opbevar emballagen utilgængeligt for børn.

Bortskaf produkter og emballage miljørigtigt.

Genbrugskoden anvendes til mærkning af forskellige materialer med henblik på genvinning. Koden består af genbrugssymbolet – som afspejler genvindingskredsløbet – og et nummer, der kendetegner materialet.

Oplysninger om garanti og servicehåndtering

Produktet er fremstillet med største omhu og under vedvarende kontrol. Der ydes en garanti på tre år fra købsdatoen på dette produkt. Opbevar venligst kvitteringen fra købet. Garantien gælder kun for materiale- og fabrikationsfejl og bortfalder ved misbrug eller uhensigtsmæssig anvendelse.

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

02.12.2020 / FM 1.07

IAN 340700_1910

6 D

DK

DK

DK

DK

DK

DK

DK

FR/BE

FR/BE

FR/BE

FR/BE

FR/BE

