


LED DECORATIVE STRING LIGHTS

 GB	 IE	 NL	 DK
LED DECORATIVE STRING LIGHTS Operation and safety notes	LED-LYSKÆDE Brugs- og sikkerhedsanvisninger		
 FR	 BE	 NL	 BE
GUIRLANDE LUMINEUSE À LED Instructions d'utilisation et consignes de sécurité	LED-LICHTDECORATIE Bedienings- en veiligheidsinstructies		
 DE	 AT	 CH	
LED-LICHTDEKORATION Bedienungs- und Sicherheitshinweise			
IAN 337084_2001		 IE	 NL
		 DK	 BE





- This article does not contain any parts which can be serviced by the user.
- The light source of this luminaries is not replaceable; when the light source reaches its end of life the whole luminaries shall be replaced.
- The string lights must not be electrically connected to another set of lights.
- Never connect the light set directly to a 230V mains supply.

⚠ Safety instructions for batteries

- ⚠ WARNING! DANGER TO LIFE!** Batteries are not intended for children. If accidentally swallowed seek immediate medical attention!
- ⚠ CAUTION! EXPLOSION HAZARD!** Never recharge non-rechargeable batteries, do not short-circuit and/ or open batteries!
- Never throw batteries into fire or water!
- Do not subject batteries to any mechanical load!

● Risk of battery leakage

- In the event of a battery leak, immediately remove it from the device to prevent damage!
- If batteries / rechargeable batteries have leaked, avoid contact with skin, eyes and mucous




 For indoor use	Til indendørs brug
Incl. Batteries	Inklusiv batterier
 Environmental damage through incorrect disposal of the batteries / rechargeable batteries!	Miljøskader gennem forkert bortskaffelse af batterierne/ akkuerne!
 Dispose of packaging and device in an environmentally-friendly way!	Bortskaf emballagen og maskinen miljøvenligt!

LED-lyskæde

● Indledning

Hjerteligt tillykke med købet af deres nye produkt. Du har besluttet dig for et produkt af høj kvalitet. Brugervejledningen er en del af dette produkt. Den indeholder vigtige informationer om sikkerhed, brug og bortskaffelse. Gør dig inden ibrugtagning af produktet fortrolig med alle betjenings- og sikkerhedsanvisninger. Benyt kun produktet som beskrevet og til de oplyste formål. Videregiv alle papirer, hvis du giver produktet videre til tredjemand.










































● Garanti og service



































Henvising: De får på dette produkt en garanti på 36 måneder fra købsdato af. Produktet er omhyggeligt produceret og kontrolleret samvittighedsfuldt inden levering. Skulle der alligevel opstå produktions- eller materialefej i garantiperioden, så bedes De venligst omgående kontakte deres faghandler.

Garantien omfatter ikke beskadigelser, der opstår gennem ikke hensigtsmæssig håndtering, ikke-overholdelse af brugsvejledningen eller indgreb gennem ikke-autoriserede personer. De fleste funktionsforstyrrelser opstår gennem fejlagtig betjening. Læs derfor først brugsvejledningen igennem i forbindelse med en radiosignalforstyrrelse.

Kontakt servicestedet hos Uni-Elektra GmbH inden eventuelle returforsendelser. Først efter aftale kan produktet modtages. Ufrankerede sendelser modtages ikke. Gennem garantien hverken forlænges eller fornyes garantiperioden på 36 måneder.



List of pictograms used	
 i	Please read the operating instructions!
 house	This product is only suitable for use indoors, in dry and enclosed rooms.
 child	Never leave children unsupervised with packaging materials and the product.
 ⚠	Observe the warning and safety instructions!
 ⚠	Caution! Explosion hazard!
 — —	Direct current / voltage
W	Watt (effective power)
Modell A approx. 1.4m approx. 0.5m	Total length approx. 1.4 m, of which approx. 0.5 m is power cable
Modell B/C/D/E approx. 1.85m approx. 0.5m	Total length approx. 1.85 m, of which approx. 0.5 m is power cable
 6h	6 hour timer which automatically repeats daily
 For indoor use	For indoor use



































Incl. Batteries included	
 Environmental damage through incorrect disposal of the batteries / rechargeable batteries!	
 Dispose of packaging and device in an environmentally-friendly way!	

LED Decorative String Lights




































● Introduction

Congratulations on the purchase of your new device. You have selected a high quality product. The instructions for use are a part of this product. They contain important information about safety, using the product and disposal. Before using the product, please familiarise yourself with all the operating and safety instructions. Only use the product as described and for its indicated purpose. When passing this product on to others, please be sure to include all its documentation.



- Intended use**

 house This product is only suitable for private use for decorating in dry indoor rooms. This product is not intended for commercial use.



- ⚠ WARNING! RISK OF LIFE AND ACCIDENTS FOR INFANTS AND CHILDREN!** Never leave children unattended with the packaging material. Risk of suffocation. Keep children away from the product.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not use the product if you notice any signs of damage.
- Never expose the product to high temperatures or moisture, as otherwise the product may be damaged.
- Ensure that the product is not subjected to a mechanical load!
- Please contact a qualified electrician in the case of damage, repairs or other problems with the light.
- ⚠ CAUTION! RISK OF OVERHEATING!** Do not operate the light set whilst it is still in the packaging.
- After use, place the light set back in the packaging to avoid it becoming unintentionally damaged.

