



IRONING BOARD



IRONING BOARD

Operation and safety notes



STRIJKPLANK

Bedienings- en veiligheidsinstructies








































































TABLE À REPASSER

Instructions d'utilisation et consignes de sécurité



BÜGELTISCH

Bedienungs- und Sicherheitshinweise



List of pictograms used
The cover is machine-washable. Set the washing machine to a delicate wash cycle at 30 °C.
The cotton cover can be ironed.
Dispose of the packaging and the ironing board in an environmentally friendly manner!

Ironing board

● Introduction






















- We congratulate you on the purchase of your new product. You have chosen a high quality product. Familiarise yourself with the product before using it for the first time. In addition, please carefully refer to the operating instructions and the safety advice below. Only use the product as instructed and only for the indicated field of application. Keep these instructions in a safe place. If you pass the product on to anyone else, please ensure that you also pass on all the documentation with it.

● Use

Note: Remove all packaging material from the product.

● Intended use

This product is an ironing board. For indoor use only. Modifying the product is prohibited and will result in damage. Misuse may also result in other life-threatening risks and injuries. This product was designed for domestic use only. It is not intended for commercial use. The manufacturer is not liable for damages due to improper use.



● Technical data

Item number: CS98090
Ironing surface: approx. 110 x 30 cm
Height: max. 90 cm
Iron rest max. load: 5 kg
Item weight: 3,90 kg
Production ID: 02 / 2021

Safety information

- ⚠️ [WARNING] DANGER TO LIFE AND RISK OF ACCIDENTS FOR INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging material. There is a danger of suffocation.



















- It is not a toy. Please keep children away from the ironing board.
- Be careful of your fingers and hands when setting up and collapsing the ironing board.
- Never attempt to repair the product yourself.
- Do not set the iron on the ironing board for extended periods.
- Do not sit or lean on the ironing board.
- Danger due hot water or steam which may drip from the expanded metal on the ironing board.
- The iron rest can get hot if used for long periods of time. To avoid burn injuries, comply with the directions given above.
- Keep the device away from water and other liquids.

● Use

Note: Remove all packaging material from the product.

● Setting up the ironing board

- Hold the folded ironing board with the ironing surface facing upwards and press the lever with your other hand. The frame will open to the maximum position (see fig. A).
- Make sure that the device is level and is fully locked into position.



● Adjusting the height of the ironing board

- To adjust the height of the ironing board, hold it with both hands. Pull on the lever to unlock.
- Adjust to your desired height and then release the lever so that the frame locks into place (see fig. B).

