



**LED WORK LIGHT PBBK 4 A1**

**LED WORK LIGHT**  
Operation and safety notes

**LED-ES MUNKALÁMPA**  
Kezelési és biztonsági utalások

**LED-REFLEKTOR**  
Navodila za upravljanje in varnostna opozorila

**LED STAVEBNÝ REFLEKTOR**  
Pokyny pro obsluhu a bezpečnostní pokyny





**LED STAVEBNÝ REFLEKTOR**  
Pokyny pre obsluhu a bezpečnostné pokyny

**LED-BAUSTRÄHLER**  
Bedienungs- und Sicherheitshinweise

DE AT CH

IAN 424999\_2301

HU SI CZ SK



**Replacing the batteries**

- WARNING! Risk of fire or explosion!** The use of incorrect batteries can lead to fire or explosion.
- NOTE:** Use only Alkaline batteries (AA) or Ni-HM rechargeable batteries (AA).
- Open the battery compartment cover [6] at the back of the product.
- Remove the old batteries.
- Insert 4 new batteries into the battery compartment [7] according to the correct polarity (+ and -).
- Close the battery compartment cover [6].

**Maintenance and cleaning**

- Never immerse the product in water or other liquids.
- Never use caustic cleaners.
- The product requires no maintenance. The LEDs cannot be replaced.
- Switch off the product before cleaning.
- Regularly clean the product with a dry, lint-free cloth. Use a slightly moist cloth to remove any stubborn dirt.

**Disposal**

The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities.

Observe the marking of the packaging materials for waste separation, which are marked with abbreviations (a) and numbers (b) with following meaning: 1–7: plastics/20–22: paper and fibreboard/80–98: composite materials.

**Product:**

Contact your local refuse disposal authority for more details of how to dispose of your worn-out product.

To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.

Faulty or used batteries/rechargeable batteries must be recycled in accordance with Directive 2006/66/EC and its amendments. Please return the batteries/rechargeable batteries and/or the product to the available collection points.

**Environmental damage through incorrect disposal of the batteries/rechargeable batteries!**

Batteries/rechargeable batteries may not be disposed of with the usual domestic waste. They may contain toxic heavy metals and are subject to hazardous waste treatment rules and regulations. The chemical symbols for heavy metals are as follows: Cd = cadmium, Hg = mercury, Pb = lead. That is why you should dispose of used batteries/rechargeable batteries at a local collection point.

**Warranty**

The product has been manufactured to strict quality guidelines and meticulously examined before delivery. In the event of product defects you have legal rights against the retailer of this product. Your legal rights are not limited in any way by our warranty detailed below.

The warranty for this product is 3 years from the date of purchase. The warranty period begins on the date of purchase. Please keep the original sales receipt in a safe location. This document is required as your proof of purchase.

Should this product show any fault in materials or manufacture within 3 years from the date of purchase, we will repair or replace it – at our choice – free of charge to you. This warranty becomes void if the product has been damaged, or used or maintained improperly.

The warranty applies to defects in material or manufacture. This warranty does not cover product parts subject to normal wear, thus possibly considered consumables (e.g. batteries) or for damage to fragile parts, e.g. switches, rechargeable batteries or glass parts.

**Warranty claim procedure**

To ensure quick processing of your case, please observe the following instructions:

Please have the till receipt and the item number (IAN 424999\_2301) available as proof of purchase.

You will find the item number on the rating plate, an engraving, on the front page of the instructions for use (bottom left), or as a sticker on the rear or bottom of the product.

If functional or other defects occur, please contact the service department listed either by telephone or by e-mail.

You can return a defective product to us free of charge to the service address that will be provided to you. Ensure that you enclose the proof of purchase (till receipt) and information about what the defect is and when it occurred.

**Service**

**Service Great Britain**  
Tel.: 0800 0569216  
E-Mail: owim@id.co.uk



| Felhasznált figyelmeztető jelzések és szimbólumok |   |
|---|---|
|   | Egyenáram-/feszültség   |
|   | III. Védelmi osztály  |
|   | Nyomja meg a BE/KI kapcsológombot [2].  |
|   | A CE-jelzés azt jelzi, hogy a termék megfelel a rá vonatkozó uniós előírásoknak |
|   | Biztonsági utalások   |
|   | Kezelési utalások   |
|   | Használat előtt olvassa el a használati útmutatót.                              |
|   | Minimális távolság a megvilágított anyagtól                                     |
|   | Tárolja gyermekektől elzárt helyen  |
|   | Ne dobja tűzbe  |
|   | Ne helyezze be helytelenül  |
|   | Ne deformálja/károsítsa   |
|   | Ne nyissa fel/szedje szét   |
|   | Ne keverjen különböző típusokat vagy márkákat                                   |
|   | Ne keverjen újakat és használtakat  |

|  |                                      |
|--|--------------------------------------|
|  | Ne tölts fel                         |
|  | Tartsa távol a túl nagy nedvességtől |
|  | Ne zárja rövidre                     |
|  | Helyezze be helyesen                 |

**LED-ES MUNKALÁMPA**

**Bevezető**

Gratulálunk új termékének vásárlása alkalmából. Ezzel a döntésével vállalatunk értékes terméke mellett döntött. A használati utasítás ezen termék része. A biztonságra, a használata és a megsemmisítésre vonatkozó fontos tudnivalókat tartalmazza. A termék használata előtt ismerje meg az összes használati és biztonsági tudnivalót. A terméket csak a leírtak szerint és a megadott felhasználási területeken alkalmazza. A termék harmadik személy számára való továbbadása esetén kézbesítse vele annak a teljes dokumentációját is.

**Rendeltetészerű használat**

- A termék normál használatra alkalmas.
- A termék kizárólag magánhasználatra alkalmas, száraz beltéri helyiségekben.
- A termék üzleti használatra vagy egyéb alkalmazásokra nem alkalmas.

**A csomagolás tartalma**

A termék kicsomagolása után ellenőrizze a csomagolás teljességét és az alkatrészek megfelelő állapotát. A használat előtt távolítsa el minden csomagolóanyagot.

- LED-es munkalámpa
- Rövid útmutató

**A részegységek leírása**

- LED-fény
- BE/KI kapcsológomb
- A csuklópánt csavarja
- Állítható láb/fogantyú
- Mágnes
- Az elemtartó rekesz fedele

| Warnings and symbols used  |   |
|--|---|
| The following warnings are used in the user manual, short manual and on the packaging: |   |
|  | Direct current/voltage  |
|  | Protection class III  |
|  | Press ON/OFF switch [2].  |
|  | CE mark indicates conformity with relevant EU directives applicable for this product. |
|  | Safety information  |
|  | Instructions for use  |
|  | Read user manual before use.  |
|  | Minimum distance to illuminated material  |
|  | Keep out of reach of children   |
|  | Do not dispose of in fire   |
|  | Do not insert incorrectly   |
|  | Do not deform/damage  |
|  | Do not open/dismantle   |
|  | Do not mix different types or brands  |
|  | Do not mix new and used   |
|  | Do not charge   |

|  |   |
|--|---|
|  | Keep away from water and excessive moisture |
|  | Do not short circuit                        |
|  | Insert correctly                            |

**LED WORK LIGHT**

**Introduction**

We congratulate you on the purchase of your new product. You have chosen a high quality product. The instructions for use are part of the product. They contain important information concerning safety, use and disposal. Before using the product, please familiarise yourself with all of the safety information and instructions for use. Only use the product as described and for the specified applications. If you pass the product on to anyone else, please ensure that you also pass on all the documentation with it.

**Intended use**

- This product is intended for normal use.
- This product is only suitable for private use in dry indoor locations.
- The product is not intended for commercial use or for use in other applications

**Scope of delivery**

After unpacking the product, check if the delivery is complete and if all parts are in good condition. Remove all packaging materials before use.

- LED work light
- Short manual

**Description of parts**

- LED light
- ON/OFF switch
- Hinge joint
- Adjustable foot/hand grip
- Magnet
- Battery compartment cover
- Battery compartment
- Battery
- Grip lock

| Technical data      |   |
|---------------------|---|
| COB LED:            | 2 x 5 W   |
| Battery:            | 4 x 1.5 V ---, Alkaline battery (AA)                          |
| Light duration:     | 2 spotlights: approx. 2 hours<br>1 spotlight: approx. 4 hours |
| Protection class:   | III/◇   |
| Protection type:    | IP20  |
| Operating position: | The product can only be used as shown in figure B.            |

**Safety instructions**

BEFORE USING THE PRODUCT, FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE! WHEN PASSING THIS PRODUCT ON TO OTHERS, ALSO INCLUDE ALL THE DOCUMENTS!

**WARNING! DANGER TO LIFE AND RISK OF ACCIDENTS FOR INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging material. Always keep children away from the packaging material.

- This product may be used by children aged 8 years and up, as well as by persons with reduced physical, sensory or mental capacities, or those lacking experience and/or knowledge provided they are supervised or instructed in the safe use of the product and they understand the associated risks. Do not allow children to play with the product. Cleaning and user maintenance must not be performed by children without supervision.
- This product is not a toy and should be kept out of the reach of children. Children are not aware of the dangers associated with handling electrical products.
- Do not use the product if you detect any type of damage.
- Never immerse the product in water or other liquids!
- Do not carry out any modifications or repairs to the product yourself. The LEDs cannot and must not be replaced.
- The LEDs are not replaceable.
- If the LEDs fail at the end of their lives, the entire product must be replaced.

**CAUTION! DANGER OF BURN INJURIES!** To prevent burns, verify the product is switched off and has cooled down for at least 15 minutes before touching it. The product can become very hot.

- The accessible surface, especially heat shrink, is very hot when the lamp is operating.

**FIRE HAZARD!** Fit the product so that it is at least 0.1 metre away from the material to be illuminated. Excessive heat can result in a fire.

- WARNING!** Do not turn on the light when the product is facing down to a combustible surface. The exposed surface may be overheated or ignited.
- Do not place burning candles or open fire on or near the product.
- Do not use the product near heat sources such as radiators or devices emitting heat.
- Dispose of the product if it is damaged.
- Immediately switch the product off if you smell burning or see smoke. Have the product examined by a qualified technician before using it again.
- Observe the usage restrictions and prohibitions of use for battery-operated products in situations which may be hazardous such as at petrol stations, airports, hospitals, etc.

**Safety instructions for batteries/rechargeable batteries**

**DANGER TO LIFE!** Keep batteries/rechargeable batteries out of reach of children. If accidentally swallowed seek immediate medical attention.

**DANGER OF EXPLOSION!** Never recharge non-rechargeable batteries. Do not short-circuit batteries/rechargeable batteries and/or open them. Overheating, fire or bursting can be the result.

- Never throw batteries/rechargeable batteries into fire or water.
- Do not exert mechanical loads to batteries/rechargeable batteries.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product and safely disposed of.
- If the product is to be stored unused for a long period, the batteries should be removed.
- The supply terminals are not to be short-circuited.

**Risk of leakage of batteries/rechargeable batteries**

- Avoid extreme environmental conditions and temperatures, which could affect batteries/rechargeable batteries, e.g. radiators/direct sunlight.
- If batteries/rechargeable batteries have leaked, avoid contact with skin, eyes and mucous membranes with the chemicals! Flush immediately the affected areas with fresh water and seek medical attention!

**WEAR PROTECTIVE GLOVES!** Leaked or damaged batteries/rechargeable batteries can cause burns on contact with the skin. Wear suitable protective gloves at all times if such an event occurs.

**Before use**

- NOTES:**
- Remove all packaging materials from the product.
  - Pull out the insulation strip from the battery compartment [7].

**Hanging the product**

- CAUTION!** A single adjustable foot/hand grip [4] is not sufficient for attaching the product to magnetisable surfaces (Fig. D).
- Each of the adjustable 2 foot/hand grips [4] is equipped with magnets [5]. With these magnets, the product can be attached to magnetisable surfaces.

**Operation**

**RISK OF ACCIDENTS!** Preferably do not use the product whilst driving a vehicle. When using the product in a vehicle, be sure this does not endanger the driver or the passengers. Always store and secure the product so that even full braking does not pose a risk of injury from the product or product damage.

- Turn the adjustable foot/hand grip [4] and attach the product at desired position. The adjustable foot/hand grip can also be turned up and used as a hand grip (Fig. B).
- The product can be attached to a flat ferromagnetic surface with the magnet [5] of the adjustable foot/hand grip.
- The product can be hung up. Press the grip lock [9] to release the adjustable foot/hand grip (Fig. C). Push the adjustable foot/hand grip back in after hanging the product at a desired position.

**CAUTION!** Please note the position of your hands whilst turning the adjustable foot/hand grip to prevent pinching your fingers.

**Using as a LED light**

- The product can be operated in 3 different modes. Select these by repeatedly pressing the ON/OFF switch [2].

| ON/OFF switch | Mode                     |
|---------------|--------------------------|
| Press 1x:     | 1 white light lights up. |
| Press 2x:     | 1 white light lights up. |
| Press 3x:     | 2 white lights light up. |
| Press 4x:     | Switch off the light.    |



