





KIDS' DESK CHAIR

GB IE NI MT

KIDS' DESK CHAIR


Assembly instructions

IAN 544942_2510



A

1x 1




1x 2




1x 3



1x 4



5x 5




1x 6



1x 7




1x 8




8x 9


















2x 10



1x 11



B**C**



**IMPORTANT, RETAIN FOR FUTURE
REFERENCE: READ CAREFULLY!**



Read carefully the following assembly instructions and store them. Use the product only as described and for the range of uses indicated.

Scope of delivery (Fig. A)

1 x swivel chair, disassembled (1-8)

1 x assembly materials (9-10)

1 x hex key (11)

1 x assembly instructions

Technical data



Maximum load: 90kg

Tested according to DIN EN 17191:2021-09



Manufacturing date (month/year):
03/2026

Intended use

This item is designed as a swivel chair for children aged 8 and above for indoor use up to a maximum of 90kg. The item is intended for private use only.

Safety instructions



Danger to life!

- Never leave children unattended with the packaging material. There is a risk of suffocation.
- Warning! Children's seating furniture placed under a window can serve as a step for the child and lead to the child falling out of the window.
- Warning! Be aware of the risk from open fire and other strong heat sources, such as radiant heaters, gas heaters, etc., in close proximity to the furniture.
- Warning! Do not place the furniture near an object that could pose an external suffocation or strangulation hazard, such as cords, blind/curtain cords, etc.



Risk of injury!

- Ensure the correct stability of the item before use.
- Place the item on a level surface.

- The item should only be used under adult supervision and not as a toy.
- The item is not a climbing or play apparatus! Ensure that people, especially children, do not pull themselves up on or lean against the item.
- Check the item for damage or wear before each use. The item should only be used in perfect condition!
- Regularly check that all screw connections are secure!
- Ensure that the item is assembled properly and according to these assembly instructions. Incorrect assembly can lead to injuries and impair safety and function.
- The gas spring should only be replaced or repaired by trained professionals.
- Never stand on the item.

Assembly

For the assembly of the item, you will need the supplied hex key (11).

1. Assemble the item as shown in Fig. B-E.

Important: Ensure that the arrow (8a) on the base plate (8) points towards the front edge of the seat (2) (Fig. C).

Note: Initially, loosely insert the screws and tighten them once the item is fully assembled.

2. Place the item on a level surface.

Note: The safety casters automatically lock when the item is not loaded, preventing unintentional rolling away when standing up (Fig. F).

Adjust seat height (Fig. G)

Increase seat height

Stand next to the item and pull the height adjustment lever (8b) upwards with one hand, without applying weight to the seat.

Decrease seat height

Sit on the item and pull the height adjustment lever upwards with one hand.

Storage, cleaning

Always store the item dry and clean at room temperature when not in use.

Vacuum the backrest and seat only. Clean the frame with a damp cleaning cloth only and then wipe dry. **IMPORTANT!** Never clean with harsh cleaning agents.



Disposal



Dispose of the product and packaging materials in accordance with current local regulations. Store the packaging materials (foil bags, for example) out of the reach of children. For further information about disposal of the product no longer needed, contact your local council. Dispose of the product and the packaging in an environmentally friendly manner.



The Recycling Code distinguishes different materials to be returned for recycling. The Code consists of the recycling symbol for the recycling process and a number that identifies the material.

Notes on the guarantee and service handling

The product was produced with great care and under continuous quality control.

DELTA-SPORT HANDELSKONTOR GmbH gives private end customers a three-year guarantee on this product from the date of purchase (guarantee period) in accordance with the following provisions. The guarantee is only valid for material and manufacturing defects. The guarantee does not cover parts that are subject to normal wear and tear and that are thus considered wear parts (e.g. batteries) and it does not cover fragile parts such as switches or parts that are made of glass.

Claims under this guarantee are excluded if the product has been used incorrectly, improperly, or contrary to the intended purpose, or if the provisions in the instructions for use were not observed, unless the end customer proves that a material or manufacturing defect exists that was not caused by one of the aforementioned circumstances.

Claims under the guarantee can only be made within the guarantee period by presenting the original sales receipt. Please therefore keep the original sales receipt. The guarantee period is not extended by any repairs carried out under the guarantee, under statutory guarantees, or as a gesture of goodwill. This also applies to replaced and repaired parts.

If you wish to make a claim please first contact the service hotline mentioned below or contact us by e-mail. If there is a guarantee case, then the product will be repaired or replaced free of charge to you or the purchase price will be refunded, depending on our choice. There are no further rights from the guarantee.

Your legal rights, in particular guarantee claims against the respective seller, are not limited by this guarantee.

IAN: 544942_2510

(GB) Service Great Britain
Tel.: 0800 404 7657
E-Mail: deltasport@lidl.co.uk

(IE) Service Ireland
(NI) Tel.: 1800 101010
E-Mail: deltasport@lidl.ie

(MT) Service Malta
Tel.: 80062230
E-Mail: deltasport@lidl.com.mt

DELTA-SPORT HANDELSKONTOR GMBH

Wragekamp 6 • 22397 Hamburg
GERMANY




03/2026

Delta-Sport-Nr.: DS-17836, DS-17837

04.08.2026 / AMT 11:03

IAN 544942_2510





GB Safety castors

Note: The safety castors automatically lock when the item is not loaded, preventing accidental rolling away when standing up.

DELTA-SPORT HANDELSKONTOR GMBH

Wragekamp 6 • 22397 Hamburg
GERMANY



03/2026

Delta-Sport-Nr.: DS-17836, DS-17837

IAN 544942_2510