



**LED WORK LIGHT PBBK 4 A1**





**LED WORK LIGHT**  
Operation and safety notes

**PROJECTEUR DE CHANTIER À LED**  
Instructions d'utilisation et consignes de sécurité

**LED-BOUWLAMP**  
Bedienings- en veiligheidsinstructies

**LED-BAUSTRÄHLER**  
Bedienungs- und Sicherheitshinweise

IAN 424999\_2301



**Warnings and symbols used**  
The following warnings are used in the user manual, short manual and on the packaging:

	Direct current/voltage
	Protection class III
	Press ON/OFF switch [2].
	CE mark indicates conformity with relevant EU directives applicable for this product.
	Safety information Instructions for use
	Read user manual before use.
	Minimum distance to illuminated material
	Keep out of reach of children
	Do not dispose of in fire
	Do not insert incorrectly
	Do not deform/damage
	Do not open/dismantle
	Do not mix different types or brands
	Do not mix new and used
	Do not charge

	Keep away from water and excessive moisture
	Do not short circuit
	Insert correctly
	UKCA mark indicates conformity with relevant Great Britain regulations applicable for this product (The UKCA mark logo is valid in Great Britain only).

**LED WORK LIGHT**

**Introduction**

We congratulate you on the purchase of your new product. You have chosen a high quality product. The instructions for use are part of the product. They contain important information concerning safety, use and disposal. Before using the product, please familiarise yourself with all of the safety information and instructions for use. Only use the product as described and for the specified applications. If you pass the product on to anyone else, please ensure that you also pass on all the documentation with it.

**Intended use**

- This product is intended for private use.
- This product is only suitable for normal use in dry indoor locations.
- The product is not intended for commercial use or for use in other applications

**Scope of delivery**

After unpacking the product, check if the delivery is complete and if all parts are in good condition. Remove all packaging materials before use.

- LED work light
- Short manual

**Description of parts**

- LED light
- ON/OFF switch
- Hinge joint
- Adjustable foot/hand grip
- Magnet
- Battery compartment cover
- Battery
- Battery
- Grip lock

**Technical data**

COB LED:	2 x 5 W
Battery:	4 x 1.5 V , Alkaline battery (AA)
Light duration:	2 spotlights: approx. 2 hours 1 spotlight: approx. 4 hours
Protection class:	III/
Protection type:	IP20
Operating position:	The product can only be used as shown in figure B.

**Safety instructions**

BEFORE USING THE PRODUCT, FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE! WHEN PASSING THIS PRODUCT ON TO OTHERS, ALSO INCLUDE ALL THE DOCUMENTS!

**WARNING! DANGER TO LIFE AND RISK OF ACCIDENTS FOR INFANTS AND CHILDREN!**  
Never leave children unsupervised with the packaging material. Always keep children away from the packaging material.

- This product may be used by children aged 8 years and up, as well as by persons with reduced physical, sensory or mental capacities, or those lacking experience and/or knowledge provided they are supervised or instructed in the safe use of the product and they understand the associated risks. Do not allow children to play with the product. Cleaning and user maintenance must not be performed by children without supervision.
- This product is not a toy and should be kept out of the reach of children. Children are not aware of the dangers associated with handling electrical products.
- Do not use the product if you detect any type of damage.
- Never immerse the product in water or other liquids!
- Do not carry out any modifications or repairs to the product yourself. The LEDs cannot and must not be replaced.
- The LEDs are not replaceable.
- If the LEDs fail at the end of their lives, the entire product must be replaced.

**CAUTION! DANGER OF BURN INJURIES!** To prevent burns, verify the product is switched off and has cooled down for at least 15 minutes before touching it. The product can become very hot.

- The accessible surface, especially heat shrink, is very hot when the lamp is operating.

**Consignes de sécurité pour piles/piles rechargeables (accus)**

**DANGER DE MORT !** Conservez les piles/piles rechargeables (accus) hors de la portée des enfants. Consultez immédiatement un médecin lors d'une ingestion accidentelle.

**RISQUE D'EXPLOSION !** Ne rechargez pas des piles non rechargeables. Ne court-circuitez jamais des piles/piles rechargeables (accus) et/ou ne les ouvrez pas. Cela peut provoquer une surchauffe, un incendie ou à des explosions.

- Ne jetez jamais de piles/piles rechargeables (accus) dans un feu ou dans de l'eau.
- Ne soumettez pas des piles/piles rechargeables (accus) à une sollicitation mécanique.
- Ne pas mélanger de types de piles différents ou des piles neuves et usagées et les utiliser ensemble.
- Les piles doivent être mises en place en respectant la polarité.
- Les piles vides doivent être retirées du produit et mises au rebut de manière sûre.
- Si le produit est stocké sans être utilisé sur une période prolongée, il faut en retirer les piles.
- Les bornes de contact ne doivent pas être court-circuitées.

**Risques dus à la fuite de piles/piles rechargeables (accus)**

- Évitez les conditions environnementales et températures extrêmes qui pourraient avoir une influence sur les piles/piles rechargeables (accus) comme p. ex. les radiateurs, l'exposition au soleil, etc.
- Si des piles/piles rechargeables (accus) ont fui, évitez tout contact de la peau, des yeux et des muqueuses avec les produits chimiques s'écoulant ! Rincez immédiatement les endroits concernés à l'eau fraîche et approchez-vous d'une assistance médicale !

**PRIÈRE DE PORTER DES GANTS PROTÉCTEURS !** Des piles/piles rechargeables (accus) endommagés ou ayant des fuites peuvent causer des brûlures lorsqu'ils entrent en contact avec la peau. Portez toujours des gants de protection appropriés dans de tels cas.

**Avant l'utilisation**

- REMARQUES :**
- Retirez tous les matériaux d'emballage du produit.
  - Enlevez la languette isolante du compartiment à piles [7].

**FIRE HAZARD!** Fit the product so that it is at least 0.1 metre away from the material to be illuminated. Excessive heat can result in a fire.

- WARNING!** Do not turn on the light when the product is facing down to a combustible surface. The exposed surface may be overheated or ignited.
- Do not place burning candles or open fire on or near the product.
- Do not use the product near heat sources such as radiators or devices emitting heat.
- Dispose of the product if it is damaged.
- Immediately switch the product off if you smell burning or see smoke. Have the product examined by a qualified technician before using it again.
- Observe the usage restrictions and prohibitions of use for battery-operated products in situations which may be hazardous such as at petrol stations, airports, hospitals, etc.

**Safety instructions for batteries/rechargeable batteries**

**DANGER TO LIFE!** Keep batteries/rechargeable batteries out of reach of children. If accidentally swallowed seek immediate medical attention.

**DANGER OF EXPLOSION!** Never recharge non-rechargeable batteries. Do not short-circuit batteries/rechargeable batteries and/or open them. Overheating, fire or bursting can be the result.

- Never throw batteries/rechargeable batteries into fire or water.
- Do not exert mechanical loads to batteries/rechargeable batteries.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product and safely disposed of.
- If the product is to be stored unused for a long period, the batteries should be removed.
- The supply terminals are not to be short-circuited.

**Risk of leakage of batteries/rechargeable batteries**

- Avoid extreme environmental conditions and temperatures, which could affect batteries/rechargeable batteries, e.g. radiators/direct sunlight.
- If batteries/rechargeable batteries have leaked, avoid contact with skin, eyes and mucous membranes with the chemicals! Flush immediately the affected areas with fresh water and seek medical attention!

**WEAR PROTECTIVE GLOVES!** Leaked or damaged batteries/rechargeable batteries can cause burns on contact with the skin. Wear suitable protective gloves at all times if such an event occurs.

**Before use**

- NOTES:**
- Remove all packaging materials from the product.
  - Pull out the insulation strip from the battery compartment [7].

**Hanging the product**

- CAUTION!** A single adjustable foot/hand grip [4] is not sufficient for attaching the product to magnetisable surfaces (Fig. D).
- Each of the adjustable 2 foot/hand grips [4] is equipped with magnets [5]. With these magnets, the product can be attached to magnetisable surfaces.

**Operation**

**RISK OF ACCIDENTS!** Preferably do not use the product whilst driving a vehicle. When using the product in a vehicle, be sure this does not endanger the driver or the passengers. Always store and secure the product so that even full braking does not pose a risk of injury from the product or product damage.

- Turn the adjustable foot/hand grip [4] and attach the product at desired position. The adjustable foot/hand grip can also be turned up and used as a hand grip (Fig. B).
- The product can be attached to a flat ferromagnetic surface with the magnet [5] of the adjustable foot/hand grip.
- The product can be hung up. Press the grip lock [9] to release the adjustable foot/hand grip (Fig. C). Push the adjustable foot/hand grip back in after hanging the product at a desired position.

**CAUTION!** Please note the position of your hands whilst turning the adjustable foot/hand grip to prevent pinching your fingers.

**Using as a LED light**

- The product can be operated in 3 different modes. Select these by repeatedly pressing the ON/OFF switch [2].

ON/OFF switch	Mode
Press 1x:	1 white light lights up.
Press 2x:	1 white light lights up.
Press 3x:	2 white lights light up.
Press 4x:	Switch off the light.

**Replacing the batteries**

- WARNING! Risk of fire or explosion!** The use of incorrect batteries can lead to fire or explosion.
- NOTE:** Use only Alkaline batteries (AA) or Ni-HM rechargeable batteries (AA).
- Open the battery compartment cover [6] at the back of the product.
- Remove the old batteries.
- Insert 4 new batteries into the battery compartment [7] according to the correct polarity (+ and -).
- Close the battery compartment cover [6].

**Maintenance and cleaning**

- Never immerse the product in water or other liquids.
- Never use caustic cleaners.
- The product requires no maintenance. The LEDs cannot be replaced.
- Switch off the product before cleaning.
- Regularly clean the product with a dry, lint-free cloth. Use a slightly moist cloth to remove any stubborn dirt.

**Disposal**

The packaging is made entirely of recyclable materials, which you may dispose of at local recycling facilities.

Observe the marking of the packaging materials for waste separation, which are marked with abbreviations (a) and numbers (b) with following meaning: 1-7: plastics/20-22: paper and fibreboard/80-98: composite materials.

**Product:**

Contact your local refuse disposal authority for more details of how to dispose of your worn-out product.

To help protect the environment, please dispose of the product properly when it has reached the end of its useful life and not in the household waste. Information on collection points and their opening hours can be obtained from your local authority.

Faulty or used batteries/rechargeable batteries must be recycled in accordance with Directive 2006/66/EC and its amendments. Please return the batteries/rechargeable batteries and/or the product to the available collection points.

**Environmental damage through incorrect disposal of the batteries/rechargeable batteries!**

Batteries/rechargeable batteries may not be disposed of with the usual domestic waste. They may contain toxic heavy metals and are subject to hazardous waste treatment rules and regulations. The chemical symbols for heavy metals are as follows: Cd = cadmium, Hg = mercury, Pb = lead. That is why you should dispose of used batteries/rechargeable batteries at a local collection point.

**Warranty**

The product has been manufactured to strict quality guidelines and meticulously examined before delivery. In the event of product defects you have legal rights against the retailer of this product. Your legal rights are not limited in any way by our warranty detailed below.

The warranty for this product is 3 years from the date of purchase. The warranty period begins on the date of purchase. Please keep the original sales receipt in a safe location. This document is required as your proof of purchase.

Should this product show any fault in materials or manufacture within 3 years from the date of purchase, we will repair or replace it – at our choice – free of charge to you. This warranty becomes void if the product has been damaged, or used or maintained improperly.

The warranty applies to defects in material or manufacture. This warranty does not cover product parts subject to normal wear, such as possibly considered consumables (e.g. batteries) or for damage to fragile parts, e.g. switches, rechargeable batteries or glass parts.

**Warranty claim procedure**

To ensure quick processing of your case, please observe the following instructions:

Please have the till receipt and the item number (IAN 424999\_2301) available as proof of purchase.

You will find the item number on the rating plate, an engraving, on the front page of the instructions for use (bottom left), or as a sticker on the rear or bottom of the product.

If functional or other defects occur, please contact the service department listed either by telephone or by e-mail.

You can return a defective product to us free of charge to the service address that will be provided to you. Ensure that you enclose the proof of purchase (till receipt) and information about what the defect is and when it occurred.

**Service**

**Service Great Britain**  
Tel.: 0800 0569216  
E-Mail: owim@lidl.co.uk

**Service Ireland**  
Tel.: 1800 200736

**Service Northern Ireland**  
Tel.: 0800 0927852  
E-Mail: owim@lidl.ie



**Avertissements et symboles utilisés**  
Les avertissements suivants sont utilisés dans le mode d'emploi, le guide de démarrage rapide et sur l'emballage :

	Courant continu/tension continue
	Classe de protection III
	Appuyer sur l'interrupteur MARCHE/ARRÊT [2].
	Le marquage CE confirme la conformité aux directives de l'UE applicables au produit
	Consignes de sécurité Instructions de manipulation
	Lisez les instructions du mode d'emploi avant l'utilisation.
	Distance minimale du matériel éclairé
	À conserver hors de la portée des enfants
	Ne pas jeter dans un feu
	Ne pas inverser la polarité
	Ne pas déformer/endommager

	Ne pas ouvrir/démanteler
	Ne pas mélanger différents types ou marques
	Ne pas mélanger des piles neuves et usagées
	Ne pas recharger
	Tenir hors de portée de l'eau et de l'humidité excessive
	Ne pas court-circuiter
	Insérer correctement
	Le marquage UKCA indique la conformité aux réglementations de la Grande-Bretagne applicables à ce produit (Le logo de marquage UKCA est valable uniquement en Grande-Bretagne).

**PROJECTEUR DE CHANTIER À LED**

**Introduction**

Nous vous félicitons pour l'achat de votre nouveau produit. Vous avez opté pour un produit de grande qualité. Le mode d'emploi fait partie intégrante de ce produit. Il contient des indications importantes pour la sécurité, l'utilisation et la mise au rebut. Veuillez lire consciencieusement toutes les indications d'utilisation et de sécurité du produit. Ce produit doit uniquement être utilisé conformément aux instructions et dans les domaines d'application spécifiés. Lors d'une session à tiers, veuillez également remettre tous les documents.

**Utilisation conforme aux prescriptions**

- Ce produit est conçu pour une utilisation normale.
- Ce produit convient uniquement à une utilisation privée dans des locaux secs.
- Ce produit n'est pas prévu pour une utilisation industrielle, commerciale ou d'autres applications.

**Contenu de l'emballage**

Après l'ouverture du produit, vérifiez l'exhaustivité de la livraison et si toutes les pièces sont en parfait état. Retirez tous les matériaux d'emballage avant l'utilisation.

- Projecteur de chantier à LED
- Guide de démarrage rapide

**Description des pièces**

- Lampe à LED
- Interrupteur MARCHE/ARRÊT
- Vis articulée
- Pied/poignée réglable
- Aimant
- Couvercle du compartiment à piles
- Compartiment à piles
- Piles
- Fermeture de la poignée

**Données techniques**

LED COB :	2 x 5 W
Piles :	4 x piles alcalines (AA) 1,5 V
Durée d'éclairage :	2 projecteurs : env. 2 heures 1 projecteur : env. 4 heures
Classe de protection :	III/
Indice de protection :	IP20
Position de fonctionnement :	Le produit doit être utilisé uniquement comme représenté sur l'illustration B.

**Consignes de sécurité**

AVANT D'UTILISER LE PRODUIT, FAMILIARISEZ-VOUS AVEC TOUTES LES CONSIGNES DE SÉCURITÉ ET LES INSTRUCTIONS DU MODE D'EMPLOI ! TRANSMETTEZ TOUS LES DOCUMENTS CONCERNANT LE PRODUIT LORSQUE VOUS LE DONNEZ À UN TIERS !

**AVERTISSEMENT ! DANGER MORTEL ET RISQUE D'ACCIDENT POUR BÉBÉS ET ENFANTS !** Ne laissez jamais des enfants sans surveillance avec des matériaux d'emballage. Maintenez toujours les enfants hors de portée des matériaux d'emballage.

- Le produit peut être utilisé par des enfants âgés de 8 ans et plus ainsi que par des personnes ayant des capacités physiques, sensorielles ou mentales réduites ou manquant d'expérience et/ou de connaissances, s'ils sont surveillés ou s'ils ont été informés de l'utilisation en toute sécurité du produit et ont compris les risques liés à son utilisation. Ne laissez pas les enfants jouer avec le produit. Le nettoyage et l'entretien ne doivent pas être effectués par des enfants sans surveillance.
- Ce produit n'est pas un jouet et doit être tenu hors de la portée des enfants. Les enfants ne sont pas conscients des dangers en relation avec l'utilisation des appareils électriques.
- N'utilisez pas le produit s'il présente des dommages visibles.
- Ne plongez jamais le produit dans de l'eau ou tout autre liquide !
- Ne réalisez pas de modifications ou de réparations sur le produit. Les diodes LED ne peuvent et ne doivent pas être remplacées.
- Les diodes LED ne sont pas remplaçables.
- Si les diodes LED ne fonctionnent plus à la fin de leur durée d'utilisation, le produit doit être remplacé dans son ensemble.

**ATTENTION ! RISQUE DE BRULURES !** Pour éviter des brûlures, soyez certain que le produit est éteint et attendez au moins 15 minutes pour qu'il refroidisse. Lorsqu'il est froid, vous pouvez le toucher. Le produit peut devenir très chaud.

- Les surfaces accessibles en particulier le tuyau thermorétractable deviennent très chauds, lors du fonctionnement de l'éclairage.
- RISQUE D'INCENDIE !** Positionnez le produit de telle sorte qu'il soit éloigné d'au moins 0,1 mètre du matériel à éclairer. Un développement de chaleur au-dessus de la normale peut conduire à un incendie.
- AVERTISSEMENT !** N'allumez pas la lumière lorsque le produit est dirigé vers une surface inflammable. La surface éclairée pourrait chauffer ou s'enflammer.
- Ne placez pas de bougies allumées ou d'autres flammes sur ou à proximité du produit.
- N'utilisez pas le produit à proximité de sources de chaleur, p. ex. près de radiateurs ou d'autres appareils qui produisent de la chaleur.
- Mettez le produit au rebut, s'il est endommagé.
- Évitez immédiatement le produit si vous sentez une odeur de brûlé ou de la fumée. Faites vérifier le produit par un technicien spécialisé, avant de l'utiliser de nouveau.
- Veuillez prendre en considération les restrictions et les interdictions pour l'utilisation de produits alimentaires par piles lors d'un fonctionnement dans des endroits potentiellement dangereux tels que des stations d'essence, des aéroports, des hôpitaux etc.

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI

GB/IE/NI + FR/BE

FR/BE

FR/BE

FR/BE

FR/BE

FR/BE

FR/BE

FR/BE

