

WATER DOODLE MAT

WASSERMALMATTE

TAPIS DE DESSIN

 GB IE NL MT	WATER DOODLE MAT
 Instructions for use DE AT CH BE	WASSERMALMATTE
 Gebrauchsanweisung FR CH BE	TAPIS DE DESSIN
 Notice d'utilisation NL BE	WATERTEKENMAT
 Gebruiksaanwijzing PL	MATA WODNA DO MALOWANIA
 Instrukcja użytkowania CZ	PODLOŽKA NA MALOVÁNÍ VODOU
 Návod k použití SK	PODLOŽKA NA MALOVANIE VODOU
 Navod na používanie ES	TAPETE DE DIBUJO DE AGUA
 Instrucciones de uso DK	VANDMALEMÅTTE
 Brugervejledning IT CH MT	TAPPETINO ACQUATICO DA PITTURARE
 Istruzioni d'uso HU	VÍZI FESTŐ MATRAC
 Használati útmutató PT	TAPETE DE PINTURA COM ÁGUA
 Manual de utilização CE	

 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	IAN 516334_2510
---	------------------------

 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	
 Bitte wenden Sie sich bei Beanstandungen zunächst an die untenstehende Service-Hotline oder setzen Sie sich per E-Mail mit uns in Verbindung. Liegt ein Garantiefall vor, wird der Artikel von uns - nach unserer Wahl - für Sie kostenlos repariert, ersetzt oder der Kaufpreis erstattet. Weitere Rechte aus der Garantie bestehen nicht. Ihre gesetzlichen Rechte, insbesondere Gewährleistungsansprüche gegenüber dem jeweiligen Verkäufer, werden durch diese Garantie nicht eingeschränkt. IAN: 516334_2510 DE Kundenservice Deutschland Tel.: 0800 5435 111 E-Mail: deltasport@lidl.de AT Service Österreich Tel.: 0800 447744 E-Mail: deltasport@lidl.at CH Service Schweiz Tel.: 0800 56 44 33 E-Mail: deltasport@lidl.ch BE Service Belgien Tel.: 0800 12089 E-Mail: deltasport@lidl.be	
 FR DELTA-SPORT HANDELSKONTOR GMBH Wragemkamp 6 • 22397 Hamburg GERMANY 04/2026 Delta-Sport-Nr.: MM-14417, MM-14418	

 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	IAN 516334_2510
---	------------------------

 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Lees aandachtig de hiernavolgende gebruiks-aanwijzing en bewaar ze. Gebruik het artikel alleen zoals beschreven en voor de aangegeven toepassingsgebieden.
 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Leveringsomvang
 1 x kleurmat 1 x waterpen (incl. opzetstift) 1 x opzetstift 1 x gebruiksaanwijzing	
 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Technische gegevens
 Afmetingen: 80 x 60 cm (b x d) 04/2026 Delta-Sport Handelskontor GmbH verklaart hierbij dat dit artikel voldoet aan de essentiële eisen en de overige relevante bepalingen.	
 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Correct gebruik
 Dit artikel is speelgoed voor kinderen vanaf 1½ jaar voor particulier gebruik. CE	
 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Veiligheidsinstructies
 • Waarschuwing. Alle verpakkingen- en bevestigingsmaterialen zijn geen bestanddeel van het speelgoed en moeten omwille van de veiligheid steeds verwijderd worden voordat het product aan de kinderen overhandigd wordt om ermee te spelen. • Kinderen mogen alleen onder toezicht van volwassensen met het artikel spelen. • Controleer het artikel vóór het gebruik op beschadigingen of slijtage. Het artikel mag alleen in een perfecte staat gebruikt worden!	
 GB IE NL DE AT CH FR BE NL PL CZ SK ES DK IT HU PT	Gebruik
 Vul de waterstift met leidingwater, zoals weergegeven in de afbeeldingen op de waterstift. Let erop, de waterstift slechts tot aan de opgedrukte markering te vullen, omdat er anders water over de waterstift kan lopen wanneer de stiftlood erop gezet wordt. Aanwijzing: Vervang de stiftloodpen doordat u de reeds vastgeschroefde stiftlood schroeft en door een andere stiftlood vervangt. Belangrijk: maak de waterstift na gebruik leeg.	

 **Read carefully the following instructions for use and store them. Use the product only as described and for the range of uses indicated.**

 GB IE NL DE AT CH BE NL PL CZ SK ES DK IT HU PT	Contents
 1 x drawing mat 1 x water pen (incl. pen attachment) 1 x pen attachment 1 x instructions for use	
 GB IE NL DE AT CH BE NL PL CZ SK ES DK IT HU PT	Technical data
 Dimensions: 80 x 60cm (W x H) Date of manufacture (month/year): 04/2026 Delta-Sport Handelskontor GmbH hereby declares that this product complies with the essential requirements and the other relevant provisions. UK Conformity Assessed Delta-Sport Handelskontor GmbH hereby declares that this product complies with the essential requirements and the other relevant provisions.	

Use according to guidelines
This product is a toy for private use and for children aged 1½ and above.

 GB IE NL DE AT CH BE NL PL CZ SK ES DK IT HU PT	Safety Instructions
 • Warning. The packaging and mounting materials are not a constitent part of the toy and they must be removed in all cases for safety reasons before the product is given to children to play with. • Children may play with this article only under adult supervision. • Check the product for damage and wear before each use. The product may only be used in good order and condition!	

Use
Fill the water pen with tap water, as shown in the illustrations on the water pen.
Be sure to fill the water brush pen only up to the printed mark since water may otherwise overflow when the pen cap is put on.
Note: To replace pen caps, unscrew the pen cap that is already screwed on and replace with another one.
Important: Empty the water pen after each use.

Storage, cleaning
When not in use, always store the product clean and dry at room temperature.
Only clean the product with a damp cloth and wipe dry afterwards. IMPORTANT! Never clean the product with harsh cleaning agents.



Disposal
 Dispose of the product and packaging materials in accordance with current local regulations. Store the packaging materials (foil bags, for example) out of the reach of children. For further information about disposal of the product no longer needed, contact your local council. Dispose of the product and the packaging in an environmentally friendly manner.
 The Recycling Code distinguishes different materials to be returned for recycling. The Code consists of the recycling symbol for the recycling process and a number that identifies the material.

Notes on the guarantee and service handling
The product was produced with great care and under continuous quality control. DELTA-SPORT HANDELSKONTOR GmbH gives private end customers a three-year guarantee on this product from the date of purchase (guarantee period) in accordance with the following provisions. The guarantee is only valid for material and manufacturing defects. The guarantee does not cover parts that are subject to normal wear and tear and that are thus considered wear parts (e.g. batteries) and it does not cover fragile parts such as switches or parts that are made of glass. Claims under this guarantee are excluded if the product has been used incorrectly, improperly, or contrary to the intended purpose, or if the provisions in the instructions for use were not observed, unless the end customer proves that a material or manufacturing defect exists that was not caused by one of the aforementioned circumstances. Claims under the guarantee can only be made within the guarantee period by presenting the original sales receipt. Please therefore keep the original sales receipt. The guarantee period is not extended by any repairs carried out under the guarantee, under statutory guarantees, or as a gesture of goodwill. This also applies to replaced and repaired parts. If you wish to make a claim please first contact the service hotline mentioned below or contact us by e-mail. If there is a guarantee case, then the product will be repaired or replaced free of charge to you or the purchase price will be refunded, depending on our choice.

 GB IE NL MT	
 GB IE NL MT	

 GB IE NL DE AT CH
--

