



FOOD STORAGE CONTAINER

GB IE NI

FOOD STORAGE CONTAINER

Instructions for use

NL

VERSHOUDOOS

Gebruiksaanwijzing

IAN 384948_2107

GB IE
NI NL

Congratulations!

You have chosen to purchase a high-quality product. Familiarise yourself with the product before using it for the first time.

 **Read the following instructions for use carefully.**

Use the product only as described and only for the given areas of application. Store these instructions for use carefully. When passing the product on to third parties, please also hand over all accompanying documents.

Package contents

1 x storage box with lid and two inlays
1 x instructions for use

Technical data

Dimensions (total): approx. 20.5 x 13.5 x 7 cm
(L x W x H)


Capacity:

1st inlay: approx. 380ml

2nd inlay: approx. 620ml

Total: approx. 1000ml

Temperature-resistant: from -20°C to +100°C

 Date of manufacture (month/year):
12/2021

Intended use

The product is for private use only, and is not intended for commercial use.

The product is suitable for use with food.

The product is suitable for dishwashers, refrigerators and freezers.

* The box is suitable for the microwave without the lid.



Food-safe



* Microwave-safe



Dishwasher-safe



Freezer-safe



Heatable to +100°C



BPA-free

Safety information

Risk of injury!

- The product is not break-proof. Do not use the product if it is damaged.
- Check the product for damage or wear before each use. Only use the product if it is in perfect condition!
- Use oven gloves when taking it out of the microwave.

Use

Fill the product and use the corresponding lid to seal in the contents. Leave approx. one finger width of space between the contents and the product's rim.

Storage, cleaning

When not in use, always store the product clean and dry at room temperature.

Clean the product carefully before using it for the first time. Clean only with water and a mild detergent, and wipe dry afterwards with a cloth.

IMPORTANT! Never clean the product with harsh cleaning agents.

Disposal

Dispose of the article and the packaging materials in accordance with current local regulations. Packaging materials such as foil bags are not suitable to be given to children. Keep the packaging materials out of the reach of children.



Dispose of the products and the packaging in an environmentally friendly manner.



The recycling code is used to identify various materials for recycling.

The code consists of the recycling symbol – which is meant to reflect the recycling cycle – and a number which identifies the material.

Service handling

IAN: 384948_2107

GB Service Great Britain

Tel.: 0800 404 7657

E-Mail: deltasport@lidl.co.uk

IE Service Ireland

NI Tel.: 1890 930 034

(0,08 EUR/Min., (peak))

(0,06 EUR/Min., (off peak))

E-Mail: deltasport@lidl.ie



Gefeliciteerd!

Met uw aankoop hebt u voor een hoogwaardig artikel gekozen. Zorg ervoor dat u voor het eerste gebruik met het artikel vertrouwd raakt.

 **Lees hiervoor de volgende gebruiksaanwijzing zorgvuldig door.**

Gebruik het artikel alleen zoals omschreven en voor het aangegeven doel. Bewaar deze gebruiksaanwijzing goed. Geef alle documenten mee als u het artikel aan iemand anders geeft.

Leveringsomvang

- 1 x bewaardoos met deksel en twee inlays
- 1 x gebruiksaanwijzing

Technische gegevens

Afmetingen (totaal): ca. 20,5 x 13,5 x 7 cm (l x b x h)


Inhoud:

1e inlay: ca. 380 ml

2e inlay: ca. 620 ml

Totaal: ca. 1000 ml

Temperatuurbestendig: van -20 °C tot +100 °C

 Productiedatum (maand/jaar):
12/2021

Beoogd gebruik

Dit artikel is uitsluitend bestemd voor particulier gebruik en niet voor zakelijk gebruik.

Het artikel is geschikt voor levensmiddelen.

Het artikel is vaatwasserbestendig en geschikt voor koelkast en diepvriezer.

* De doos is zonder deksel geschikt voor de magnetron.



Geschikt voor levensmiddelen



* Geschikt voor magnetron



Geschikt voor vaatwasser



Geschikt voor diepvriezer



Tot +100 °C te verhitten



BPA-vrij

Veiligheidstips

Kans op lichamelijk letsel!

- Het artikel is niet breukvast. Gebruik het artikel niet wanneer het beschadigd is.
- Controleer het artikel voor elk gebruik op beschadigen of slijtage. Het artikel mag alleen in goede staat worden gebruikt!
- Gebruik ovenwanten om het uit de magnetron te halen.

Gebruik

Vul het artikel met inhoud en sluit het artikel af met het bijbehorende deksel. Vul het artikel slechts tot ca. een vingerbreedte onder de rand.

Opslag, reiniging

Bewaar het artikel wanneer u dit niet gebruikt altijd droog en schoon op kamertemperatuur.

Reinig het artikel zorgvuldig voor het eerste gebruik.

Reinig het artikel alleen met water en een mild reinigingsmiddel en veeg het vervolgens droog met een schoonmaakdoek.

BELANGRIJK! Reinig nooit met agressieve reinigingsmiddelen.

Afvalverwerking

Voer het artikel en verpakkingsmaterialen in overeenstemming met actuele lokale voorschriften af. Verpakkingsmaterialen, zoals bv. foliezakjes, horen niet thuis in kinderhanden. Berg het verpakkingsmateriaal buiten het bereik van kinderen op.



Voer de producten en verpakkingen op milieuvriendelijke wijze af.



De recyclingcode dient om verschillende materialen te kenmerken ten behoeve van hergebruik via het recyclingproces.

De code bestaat uit het recyclingsymbool, dat het recyclingproces weerspiegelt, en een getal dat het materiaal identificeert.

Serviceafhandeling

IAN: 384948_2107

 Service Nederland

Tel.: 0900 0400223 (0,10 EUR/Min.)

E-Mail: deltasport@lidl.nl

DELTA-SPORT HANDELSKONTOR GMBH

Wragekamp 6 • DE-22397 Hamburg
GERMANY



12/2021

Delta-SportNr.: AD-10627, AD-10628,
AD-10629, AD-10630

12.28.2021 / PM 12:00

IAN 384948_2107

