


/// PARKSIDE



PDF ONLINE
www.lidl-service.com

CORDLESS LED WORK LIGHT PAS 2200 D4


CORDLESS LED WORK LIGHT Operation and safety notes

PROJECTEUR LED SANS FIL Instructions d'utilisation et consignes de sécurité

ACCU-LED-SCHIJNWERPER Bedienings- en veiligheidsinstructies

AKKU-LED-STRAHLER Bedienungs- und Sicherheitshinweise

IAN 471028_2407



CORDLESS LED WORK LIGHT Operation and safety notes

1. Introduction Congratulations!

With your purchase you have chosen a high-quality product. The operation and safety notes are an integral part of this product. They contain important information for safety, use and disposal. Familiarise yourself with all of the operation and safety notes before using the product. Use the product only as described and for the specific areas of application. Keep the operation and safety notes for future reference. Provide all of the documentation when passing the product on to third parties.

In the following, the Cordless LED Work Light is referred to as the product.

Explanation of symbols

The following symbols and signal words are used in these operation and safety notes, on the product or on the packaging.

WARNING!

This signal symbol/word indicates a hazard with a high level of risk which, if not avoided, may result in death or serious injury.

CAUTION!

This signal symbol/word indicates a hazard with a low level of risk which, if not avoided, may result in minor or moderate injury.

NOTE!

This signal word warns of possible property damage or provides you with useful additional information regarding the use.

2. Safety Intended use

The product is not intended for commercial use. Different use or a modification to the product are not deemed as intended use and may lead to risks, such as injuries and damage. The distributor assumes no liability for damage that results from improper use.

- The product is intended for indoor and outdoor use.
- The product is not suitable for household room lighting.

The product is intended as a mobile work lamp.

The product is suitable for use in harsh environments.

Use USB-C cable(s) only in dry and sheltered rooms.

3. Scope of delivery (Fig. A)

- 1x Spotlight housing with carrying handle and metal bracket
- 1x Hand screw
- 1x Washer
- 1x Snap ring
- 1x Stand base
- 1x USB-C cable
- 1x Operation and safety notes (without fig.)

4. Technical specifications

Type: Cordless LED Work Light
IAN: 471028_2407
Tradix Item No.: 471028-24-A
Operating voltage: 3,7 V
Total output: max. 10 W
Lithium-ion battery: 3,7 V, 2200 mAh, Type: 18650, (non-replaceable, hereinafter referred to as battery)
USB-C connection: 5V --- 1A
Illuminant: 9 LEDs, each 0,9 W (white, not replaceable)
Projection surface: 9,4 x 9,4 cm (approx. 88 cm²)
Burn time: 1,5 hours
Dimensions: approx. 21,7 x 12 x 13,5 cm
Protection class: III/0
Protection type: IP54
Production date: 11/2024
Warranty: 3 years

5. Safety information

WARNING!

Risk of injury and suffocation!

- If children play with the product or the packaging, they may injure themselves or suffocate.
- Do not let children play with the product or the packaging.
- Supervise children who are close to the product.
- Keep the product and the packaging out of the reach of children.

WARNING!

Risk of injury!

- Children from the age of 8, as well as people with impaired physical, sensory or mental capabilities or with a lack of experience and knowledge, must be supervised when using the product and/or be instructed regarding the safe use of the product and understand the resulting dangers.
- Children are not allowed to play with the product.
- Maintenance and/or cleaning of the product is not allowed to be performed by children.

Observe national regulations!

- Observe the applicable national requirements and regulations for the use and disposal of the product.

WARNING!

Risk of injury!

- Do not use in an explosive environment! There is a risk of injury!
- The product is not allowed to be used in an explosive (Ex) environment. The product is not approved for an environment, in which flammable liquids, gases or dust are present.

WARNING!

Risk of glaring!

- Do not look directly into the light of the lamp and do not point the lamp at other people's eyes. This can impair the eyesight.

WARNING!

Risk of injury!

- A defective product is not allowed to be used! There is a risk of injury!
- Do not use the product in the case of malfunctions, damage or defects.
- Significant danger can occur for the user in the case of improper repairs.
- If you find a defect in the product, have the product checked and repaired if necessary before putting it back into operation.
- The LEDs and the battery are not replaceable. If the LEDs or battery are defective, the product must be disposed of.

WARNING!

Risk of injury!

- Manipulations/modifications are prohibited for approval reasons (CE).
- The product must not be covered up during use.

WARNING!

Risk of injury!

- Manipulations/modifications are prohibited for approval reasons (CE).
- The product must not be covered up during use.

6. Safety instructions regarding rechargeable batteries

WARNING!

Overheating and explosion hazard!

- Keep the product away from heat sources and direct sunlight, the battery may explode if overheated.
- There is a risk of injury.
- Do not operate the product in its packaging! There is a risk of fire!

WARNING!

Risk of injury!

- Wear gloves!
- Do not touch leaked batteries with bare hands! There is a risk of injury!

- Leaked or damaged batteries may cause acid burns if they come into contact with skin. Do not touch leaked batteries with bare hands; therefore, ensure that you wear appropriate protective gloves in such a case!

NOTE!

- The product has a built-in rechargeable battery that cannot be replaced by the user. In order to avoid hazards, the battery may only be removed by the manufacturer or its service agent or by a similarly qualified individual.
- When disposing of the product, please note that the product contains a rechargeable battery.

CAUTION!

Danger of overheating!

- Remove packaging prior to use.

7. Start-up

- Remove all packaging materials.
- Check whether all parts are available and undamaged.
- If this is not the case, notify the specified service address.

8. Mounting the stand base (Fig. B)

- Mount the spotlight housing with the metal bracket as shown with the hand screw, washer and snap ring on the stand base, see Fig. B.
- Turn the hand screw hand-tight closed.

9. Charging the battery (Fig. C)

- The battery must be charged for 12 hours before the first use.
- The battery must be charged as soon as the LEDs light up less brightly and the charging indicator lights up red.

NOTE!

The product must not be mounted with the metal bracket e.g. on a wall.

10. Carrying the product

- Only carry the product using the designated carrying handle.

NOTE!

The product is not allowed to be hung on the carrying handle.

11. Setting up the product

- Set up the product in an appropriate place.

NOTE!

The product should be even, so that the product cannot fall over. The place should have sufficient free space around the product.

12. Switching the product on/off

- To switch on/off, press the ON/OFF button.
- See Fig. C. A clicking sound can be heard when pressing the button.

13. Changing the light alignment

- By loosening both of the locking screws on the side of the spotlight unit, change the light alignment vertically as shown, see Fig. D a). After adjustment, retighten the locking screws hand-tight.
- You can rotate the spotlight housing in the horizontal alignment. Loosen the hand screw and rotate the spotlight housing in the desired direction, see Fig. D b). After adjustment, rotate the hand screw hand-tight again.

14. Cleaning and care instructions

- Watch your fingers when adjusting the product. You could possibly trap them.

15. Conformity declaration

- This device complies with the fundamental requirements and other relevant regulations of the European Electromagnetic Compatibility Directive 2014/30/EU and the RoHS Directive 2011/65/EU. The complete original conformity declaration is available from the importer.

16. Disposal

- The packaging and instructions are made of environmentally friendly materials that you can dispose of at local recycling points.

17. Warranty

- The warranty begins on the date of purchase. Please keep the original receipt. This document is required as verification of the purchase.
- If a material or manufacturing defect arises within three years from the purchase date of this product, the product will be repaired or replaced, as per our choice, at no charge to you. This warranty service requires the submission of the purchase receipt and the defective product within the three-year period and a short written description of the defect and when it arose.
- If the defect is covered by our warranty, the repaired or a new product will be returned to you. The warranty period does not restart with the repair or replacement of the product.

18. Guarantee period and statutory claims for defects

- The guarantee period will not be extended by the warranty. This also applies to replaced and repaired parts. Damage and defects which may possibly already exist upon purchase must be reported immediately after unpacking. After the guarantee period has expired, required repairs shall be subject to a charge.

7. Close the switch button Press the cover

The product is now ready to use.

NOTE!

The product should be recharged once a month if it is not used for a long period of time. If the product has not been charged for a long period of time (approx. 2 months), the battery will be in the idle state. Then the product should be charged and discharged several times to reactivate the battery.

10. Carrying the product

- Only carry the product using the designated carrying handle.

NOTE!

The product is not allowed to be hung on the carrying handle.

NOTE!

The surface should be even, so that the product cannot fall over. The place should have sufficient free space around the product.

12. Switching the product on/off

- To switch on/off, press the ON/OFF button.
- See Fig. C. A clicking sound can be heard when pressing the button.

13. Changing the light alignment

- By loosening both of the locking screws on the side of the spotlight unit, change the light alignment vertically as shown, see Fig. D a). After adjustment, retighten the locking screws hand-tight.
- You can rotate the spotlight housing in the horizontal alignment. Loosen the hand screw and rotate the spotlight housing in the desired direction, see Fig. D b). After adjustment, rotate the hand screw hand-tight again.

14. Cleaning and care instructions

- Watch your fingers when adjusting the product. You could possibly trap them.

15. Conformity declaration

- This device complies with the fundamental requirements and other relevant regulations of the European Electromagnetic Compatibility Directive 2014/30/EU and the RoHS Directive 2011/65/EU. The complete original conformity declaration is available from the importer.

16. Disposal

- The packaging and instructions are made of environmentally friendly materials that you can dispose of at local recycling points.

17. Warranty

- The warranty begins on the date of purchase. Please keep the original receipt. This document is required as verification of the purchase.
- If a material or manufacturing defect arises within three years from the purchase date of this product, the product will be repaired or replaced, as per our choice, at no charge to you. This warranty service requires the submission of the purchase receipt and the defective product within the three-year period and a short written description of the defect and when it arose.
- If the defect is covered by our warranty, the repaired or a new product will be returned to you. The warranty period does not restart with the repair or replacement of the product.

18. Guarantee period and statutory claims for defects

- The guarantee period will not be extended by the warranty. This also applies to replaced and repaired parts. Damage and defects which may possibly already exist upon purchase must be reported immediately after unpacking. After the guarantee period has expired, required repairs shall be subject to a charge.

19. Processing in the case of a guarantee claim

- To ensure quick processing of your concern, please follow the instructions below:
- Please have the bill receipt and article number available (IAN 471028_2407 as proof of the purchase.
- You can find the article number on the rating plate on the product, as an engraving on the product, the title place of your instructions or the sticker on the back or underside of the product.
- If malfunctions or other defects occur, first contact the service department below by telephone or e-mail.
- You can then send a product that has been recorded as being defective, including the proof of purchase (bill receipt) and stating what the defect is and when it occurred, postage-free to the service address provided to you.

20. On www.lidl-service.com, you can download these and many other manuals, product videos and installation software.

21. With this QR code, you can directly reach the Lidl Service website.

22. This QR code, you can directly reach the Lidl Service website.

23. This QR code, you can directly reach the Lidl Service website.

24. This QR code, you can directly reach the Lidl Service website.

25. This QR code, you can directly reach the Lidl Service website.

26. This QR code, you can directly reach the Lidl Service website.

27. This QR code, you can directly reach the Lidl Service website.

28. This QR code, you can directly reach the Lidl Service website.

29. This QR code, you can directly reach the Lidl Service website.

30. This QR code, you can directly reach the Lidl Service website.

31. This QR code, you can directly reach the Lidl Service website.

32. This QR code, you can directly reach the Lidl Service website.

33. This QR code, you can directly reach the Lidl Service website.

34. This QR code, you can directly reach the Lidl Service website.

35. This QR code, you can directly reach the Lidl Service website.

36. This QR code, you can directly reach the Lidl Service website.

37. This QR code, you can directly reach the Lidl Service website.

38. This QR code, you can directly reach the Lidl Service website.

39. This QR code, you can directly reach the Lidl Service website.

40. This QR code, you can directly reach the Lidl Service website.

41. This QR code, you can directly reach the Lidl Service website.

42. This QR code, you can directly reach the Lidl Service website.

43. This QR code, you can directly reach the Lidl Service website.

44. This QR code, you can directly reach the Lidl Service website.

45. This QR code, you can directly reach the Lidl Service website.

46. This QR code, you can directly reach the Lidl Service website.

47. This QR code, you can directly reach the Lidl Service website.

48. This QR code, you can directly reach the Lidl Service website.

49. This QR code, you can directly reach the Lidl Service website.

50. This QR code, you can directly reach the Lidl Service website.

51. This QR code, you can directly reach the Lidl Service website.

52. This QR code, you can directly reach the Lidl Service website.

53. This QR code, you can directly reach the Lidl Service website.

54. This QR code, you can directly reach the Lidl Service website.

55. This QR code, you can directly reach the Lidl Service website.

56. This QR code, you can directly reach the Lidl Service website.

57. This QR code, you can directly reach the Lidl Service website.

58. This QR code, you can directly reach the Lidl Service website.

59. This QR code, you can directly reach the Lidl Service website.

60. This QR code, you can directly reach the Lidl Service website.

61. This QR code, you can directly reach the Lidl Service website.

62. This QR code, you can directly reach the Lidl Service website.

63. This QR code, you can directly reach the Lidl Service website.

64. This QR code, you can directly reach the Lidl Service website.

65. This QR code, you can directly reach the Lidl Service website.

66. This QR code, you can directly reach the Lidl Service website.

67. This QR code, you can directly reach the Lidl Service website.

68. This QR code, you can directly reach the Lidl Service website.

69. This QR code, you can directly reach the Lidl Service website.

70. This QR code, you can directly reach the Lidl Service website.

71. This QR code, you can directly reach the Lidl Service website.

72. This QR code, you can directly reach the Lidl Service website.

73. This QR code, you can directly reach the Lidl Service website.

74. This QR code, you can directly reach the Lidl Service website.

75. This QR code, you can directly reach the Lidl Service website.

76. This QR code, you can directly reach the Lidl Service website.

77. This QR code, you can directly reach the Lidl Service website.

78. This QR code, you can directly reach the Lidl Service website.

79. This QR code, you can directly reach the Lidl Service website.

80. This QR code, you can directly reach the Lidl Service website.

81. This QR code, you can directly reach the Lidl Service website.

82. This QR code, you can directly reach the Lidl Service website.

83. This QR code, you can directly reach the Lidl Service website.

84. This QR code, you can directly reach the Lidl Service website.

85. This QR code, you can directly reach the Lidl Service website.

86. This QR code, you can directly reach the Lidl Service website.

87. This QR code, you can directly reach the Lidl Service website.

88. This QR code, you can directly reach the Lidl Service website.

89. This QR code, you can directly reach the Lidl Service website.

90. This QR code, you can directly reach the Lidl Service website.

91. This QR code, you can directly reach the Lidl Service website.

92. This QR code, you can directly reach the Lidl Service website.

93. This QR code, you can directly reach the Lidl Service website.

94. This QR code, you can directly reach the Lidl Service website.

95. This QR code, you can directly reach the Lidl Service website.

96. This QR code, you can directly reach the Lidl Service website.

97. This QR code, you can directly reach the Lidl Service website.

98. This QR code, you can directly reach the Lidl Service website.

99. This QR code, you can directly reach the Lidl Service website.

100. This QR code, you can directly reach the Lidl Service website.

101. This QR code, you can directly reach the Lidl Service website.

102. This QR code, you can directly reach the Lidl Service website.

103. This QR code, you can directly reach the Lidl Service website.

104. This QR code, you can directly reach the Lidl Service website.

105. This QR code, you can directly reach the Lidl Service website.

106. This QR code, you can directly reach the Lidl Service website.

107. This QR code, you can directly reach the Lidl Service website.

108. This QR code, you can directly reach the Lidl Service website.

109. This QR code, you can directly reach the Lidl Service website.

110. This QR code, you can directly reach the Lidl Service website.

111. This QR code, you can directly reach the Lidl Service website.

112. This QR code, you can directly reach the Lidl Service website.

113. This QR code, you

